



Wine Stack Rack Assembly Instructions



Congratulations! You have purchased the finest wine racking available anywhere. Please call us toll-free at **888-812-4427** if you have any questions or problems.

Tools Required for Assembly:


- No Tools Required

Parts List:


Before starting, carefully review the parts and quantities against the parts list to make sure you have everything you need. Then read through the instructions, taking time to familiarize yourself with the pieces and steps.

Wine Stack Rack

- 1 Front Panel
- 1 Back Panel
- 2 Side Panels



Front Panel




Back Panel



Side Panel
(inside view)

Parts List



Exploded View

Steps to Assembly

1. Locate the front and back panels. Arrange them parallel to one another (**Figure 1**).




Figure 1

2. Take the first side panel and slide the grooves over the ends of both the front and back panels until the top is flush (**Figure 2**).




Figure 2

3. Slide the remaining side panel over the opposite end of the front and back panels until top is flush (Figure 3).






Figure 3



Stack Rack Assembled

The stack rack should be stacked on a flat surface and it is recommended not to exceed 5 racks high. For added stability, turn the white tabs on the inside of each stack rack down to prevent the rack from sliding off sideways.



Stacked

Note: Be sure to load your stacked racks from the bottom up. Loading the stack rack from the top to the bottom will make the racks top heavy and therefore increase the likelihood of them falling.

Additional installation questions?
Contact us:



VIGILANT, INC.
85 Industrial Park Drive
Dover, NH 03820
Toll Free 1-888-812-4427
Outside US 1-603-285-0400
Fax 1-603-285-0420
email: info@vigilantinc.com
On the web www.vigilantinc.com